To: Bob Bailey

Gary Butts - APG
Dave Christensen - APG
Mike Clark - APG
Burrell Smith

From: Peter Ashkin

Subj: Front Desk Bus - An Alternative Proposal

To make the "Front Desk Bus" a more flexible and powerful interface, I believe that it should have the following properties:

- 1. The bus shall be bidirectional. [An input only bus is too restrictive.]
- 2. Each device on the bus has a unique address. For practical purposed the address range should be 0 15. Some of these addresses may be reserved for broadcasting universal messages. [This seems like a sane number of devices, particularly since there exists today only three devices; keyboard, keypad and mouse.]
- 3. All messages on the bus shall be fixed length. [This facilitates the decoding of commands by devices of limited intelligence.]
- 4. Only one device at a time can be "bus master". This ability can be relinquished, and another device can assume bus mastership. [Usually the host will be the bus master, but the interface should not preclude a future device which may master the bus. Also, by having an undisputed bus master, there are no bus contention problems.]
- 5. There shall be a limited number of commands. Commands should be broken into two groups, basic commands (TALK and LISTEN) which all devices on the bus shall understand; and advanced commands which only intelligent devices (as appropriate) should understand. [This makes the command interpreter, be it hardware or software, simple. It also allows more complex devices to used some of the "fancier" features of the bus.]
- 6. There shall be only one active talker on the bus at any time, this may be the host or a remote device. [When a new device is commanded to TALK, an old device that was addressed to TALK is "untalked".]

August 20, 1984

Date:


- 7. Bus must accept devices that talk at different speeds. The host, at a minimum, must be able to listen at various speeds. [This implies that the data on the bus must be "self-clocked". By not rigidly fixing the speed of transmission, the bus does not need to be crystal (etc.) controlled.]
- 8. There can be multiple active listeners on the bus. [Listen commands are additive, as needed, multiple devices can be addressed to listen. To remove a selected listener, a special "unlisten" command is sent to globally deselect all listeners.]
- 9. An interrupt mechanism must be available which circumvents the needs to poll devices that need service. [Since the bus is relatively slow, the interrupt latency time in a polled environment is long. The ability to interrupt the master for service is important.]
- 10. There shall exist a mechanism that sends a unique message that puts all devices on the bus into the command (reset) mode. [This is important if for some reason the bus gets "hung".]
- 11. There should be a minimum number of "time-outs" needed on the bus. The only needed time out should be to time out a non-responsive talker. [Timers are ugly, but waiting for a dead device is uglier.]
- 12. Hand-off of the bus from the master to a talker, or from the master to another master must be without bus contention. [Contentions hurt output drivers and are noisey. The pullup of the bus if it is actively driven must go tristate when inactive on the bus.]

## Commands:

There are two major command groups; basic commands and advanced commands. All devices on the bus shall understand at least one command in the basic group and optionally understand commands in the advanced group.

## BASIC Command Group:

There are two commands in this group; TALK and LISTEN.



Note that the MSB of all commands is set to "1". Only the bus master has the ability to drive the MSB of any transaction on the bus to a "1". Conversely, all data transactions have the MSB set to "0". The bus master as well as any other device on the bus has the ability to set the MSB to "0".

The next two bits form the command: "11" for TALK and "10" for LISTEN. All devices on the bus must obey at least one of these commands. Keyboards, numeric keypads and mice as a minimum must respond to the "00" TALK command. When a device is addressed to TALK, it must respond before being timed out by the host. This timeout as suggested by APG might be in the range of 200us. [This is reasonable for devices that are microcomputer based. The GI PIC series of processors that APG will use executes an instruction in approximately 2us.] The selected device then becomes active on the bus, performs its nine bit transaction then unselects itself and goes inactive on the bus. Thus talk commands transfer only a single byte at a time and a new TALK command must be issued to read the next byte.

When a device is addressed to LISTEN, it is enabled to accept data transaction from the host or other bus device. Multiple devices can be addressed to LISTEN simultaneously. This is done by sending multiple LISTEN commands to different listen addresses. Devices that are


addressed to LISTEN remain listeners until either specifically commanded to "unlisten" by issuing a LISTEN command to reserved listen address 15 (which unlistens all devices that are listeners), or addressed to TALK (devices cannot be simultaneously a talker and a listener.) As an example:

:device 7 commanded to listen LISTEN 7 LISTEN 14 :devices 7 and 14 both commanded to listen TALK 2 :device 2 commanded to send a byte or timeout (data byte) sent by device 2 received by devices 7, 14 and master TALK 2 :send another byte (data byte) :another byte from device 2 LISTEN 15 :unlisten command LISTEN 14 :turn on device 14 to listen again sent by bus master to device 14 (data byte) (data byte) :ditto :etc

The next field is a two bit register address field. This field, which is optional, allows a specific register within an addressed device to be specified. An example of where this might be used is to differentiate a data register (in a keyboard, the specific keystroke) from a status/configuration register (in a keyboard, a response that signifies the model of the keyboard). Finally there is a four bit device address field which specifies the address of the selected device. These addresses range from 0 - 14. Address 15 is the unlisten address for LISTEN commands and the TALK alias address of the present bus master.

## **Advanced Command Group:**

There are four commands in this group; PASS (bus mastership), ENABLE (interrupt), DISABLE (interrupt) and IDENTIFY. There are also four reserved commands for future expansion.



Note that the MSB of these commands is again set to "1". The defined

4

Front Desk Bus

August 24, 1984

advanced commands have the next two bits set to "00".


The PASS command is used to pass bus mastership from the present bus master to a new bus master. Once bus mastership is relinquished, the old bus master behaves as any other device on the bus, and loses the ability to drive the MSB to "1" (loses the ability to send commands). The PASS command has its command bits set to "11".

The next three commands deal with the ability of devices on the bus to interrupt the bus master. This is useful in systems where the interrupt response time in a polled system is longer than desired. ENABLE allows selected devices to signal an interrupt on the bus, or conversely DISABLE selectively inhibits the signalling of an interrupt. When an enabled device signals an interrupt, the bus master may not know which device has signalled. This is because multiple devices may be enabled simultaneously. (Thus the command is additive, enabling one device does not disable any previously enabled device.) An IDENTIFY command may be issued to request that the interrupting device talk and send its address as a data transaction.

"00"	ENABLE		
"01"	DISABLE		
"10"	IDENTIFY		
"11"	PASS		

The PASS command has the property that it globally disables all devices. They must be explicitly re-enabled by the new bus master. ENABLE and DISABLE require that the address of the desired device be specified. The range is 0 - 14. Address 15 is a reserved address for the DISABLE command and serves as a global disable. The IDENTIFY does not require an address to be specified, the address field in the instruction is a "don't care".

To allow for future expansion of the command structure, a group of "place holder" **RESERVED** instructions has been defined. These instructions shall be treated as no-ops.



## Command syntax:

TALK	1 11	$R_1R_0$	$A_3A_2A_1A_0$
LISTEN	1 10	$R_1R_0$	$A_3A_2A_1A_0$
ENABLE	1 00	00	$A_3A_2A_1A_0$
DISABLE	1 00	01	$A_3A_2A_1A_0$
IDENTIFY	1 00	10	XXXX
PASS	1 00	11	$A_3A_2A_1A_0$
RESERVED	101	XX	XXXX